

Introduction

Britmet Lightweight Roofing's granulated metal tile systems (including, Shingle, Slate 2000, Ultratile, Villatile, Profile 49, and Plaintile) have an Alu-zinc steel base with an acrylic resin base coat and a stone granule top coat with a clear acrylic overglaze. However, our coatings, (like all water-based coatings) need to be protected whilst handling and when fitting.

If damage does occur whilst handling and fixing the granulated metal tiles and flashings, we have touch-up kits available that will repair any damage caused when applied with care and it will not minimise the effectiveness of the total coating.

Directions

1. Clean off excess paint/debris from the affected area.
2. Brush apply the colour Acrylic undercoat over the affected area.
3. Whilst the undercoat is still wet, apply the Stone granules, covering the complete wet surface.
4. Leave to dry for approximately three to four hours.

Note: If rust is showing, then the material will have to be cleaned down with a wire brush so that all the rust is cleared. 2 coats of Anti-Firtan should then be applied, and the above following steps to be taken.

Things to Note

1. These instructions must be carried out in dry/frost-free conditions.
2. Any damaged areas must be free from dirt or grease.
3. The Acrylic base coat must be applied first.
4. When the Acrylic coating is still wet, the Stone granules topcoat can be applied.

Providing that these guidelines are followed, the making good of the damaged areas will not affect the 40-year weather penetration guarantee.

Tiles must be covered when stacked. All products must be lifted when moving, not dragged. Pallets should be stacked singly.